



HERE+ GNSS USER GUIDE

V1.0
Aug 2017

Content

1) Upgrading to U-blox 1.30 Firmware.....	3
a) Downloading U-centre UI and 1.30 Firmware.....	3
b) Connect your HERE+ Base and Rover to Computer	4
c) Upgrading Process	5
d) Check current Rover/Base firmware version	8
2) Basic Operating Manual	9
a) Use Mission Planner for Base module surveying/ Rover module positioning.....	9
i) Preparation before Operation.....	9
ii) Base Module setting using Mission Planner.....	11
iii) Rover Module and Flight Controller Setup.....	14
b) Use U-centre for live data recording/replaying	15
3) Use U-Centre for debugging/advanced configuration	16
a) Check Status of Base Station	16
b) Check whether Rover receives base correction data(Timeout).....	17
c) Set Survey-in/Fixed mode for base station.....	17
d) Use Beidou/GLonass	18
e) Base module I/O port and protocol setup	19
f) Change Rover module output rate.....	20
4) Change Base Antenna and Testing.....	21




1) Upgrading to U-blox 1.30 Firmware

The default firmware version of the HERE + modules is ublox-1.10 firmware. The new version of 1.30 firmware includes new feature of fusing other satellite systems (Glonass / beidou) with GPS for RTK operations, effectively increasing the RTK positioning accuracy. Therefore, it is recommended that all users upgrade to 1.30 firmware before using HERE+.

During the preparation of this guide, ublox-1.40 version of the firmware has also been released. 1.40 version firmware introduced a new feature called the mobile base station, that is, the base station need not be fixed in a location. For example, a base station may be placed on a moving vehicle or boat. Upgrading to Ublox-1.40 version is similar to upgrading to 1.30. For users who do not need to use the mobile baseline feature, upgrading to version 1.30 is sufficient.

a) Downloading U-centre UI and 1.30 Firmware

Upgrading firmware requires the use of Ublox's Windows software U-center. To download U-center, please go to the official website link: <https://www.u-blox.com/en/product/u-center-windows>. Then follow the prompts to install U-cent software. During the installation process, you will be prompted to install the device Driver, please ensure that only the Standard Driver For Windows is checked, as shown below.




You will also need to download firmware at: <https://www.u-blox.com/en/search?keywords=HPG+1.30>. Click the choice: u-blox M8 Flash Firmware 3.01 HPG 1.30 - ONLY for High Precision GNSS products.

b) Connect your HERE+ Base and Rover to Computer

When upgrading the base station module, use the USB cable to connect the base station module to the computer USB interface, as shown in the following figure:




When upgrading a Rover module, use a hexagonal screwdriver to open the case. The rover module has a USB interface connector identical to the base module, you can use the base module USB cable to connect rover to computer. In addition, during the firmware upgrading process, the rover module needs to be powered by connecting to flight controller, as shown in the following figure:




c) Upgrading Process


Open the U-center software, click the connection button (as shown in the red circle), select the com port that corresponds to your base/ rover module.



Click tools->u-blox 5 – 8 Flash Firmware Update, and click the settings as shown below:




In Firmware image, unzip and select the downloaded 1.30 Firmware. For base module, chose the firmware with title:
UBX_M8_301_HPG_130_REFERENCE_NEOM8P2.59a07babb501ba6a89ff87cac2f 2765f.bin
For rover module, choose the firmware:
UBX_M8_301_HPG_130_ROVER_NEOM8P0.3ee86a9e4775e3335e742b53527fa5 d0.bin



In Flash Information Structure(FIS) File, select Flash.xml , which is located in the installation address of U-centre software.






Click OK and wait for the firmware uploading to complete. Uploading usually takes only a minute or less. If the uploading is successful, the upgrade interface is displayed in green; if the upgrade is aborted, the interface is displayed in red. If the process is interrupted, or if it is not responding for a long time, the modules will need to be power cycled and uploading needs to be done again.

d) Check current Rover/Base firmware version

When base/rover is already connected to U-centre, click View, go to Message View -> UBX -> MON -> VER, you will see the interface below:



As shown in the figure, the current firmware version is FWVER = HPG 1.30 REF, indicating that the current firmware version is 1.30 for base module.



2) Basic Operating Manual


a) Use Mission Planner for Base module surveying/ Rover module positioning

This part of the tutorial uses Mission Planner ground control software and Arducopter-3.5 flight control firmware for operating instructions. If you are using PX4 firmware and QGroundControl ground station software, please refer to the link:

https://docs.px4.io/en/advanced_features/rtk-gps.html .

i) Preparation before Operation

To use HERE + on a UAV, you need the following hardware:



Before using, make sure the hardware is connected correctly:

The base station module is connected to the computer port through USB; a telemetry module is connected to another USB port of the same computer.

For UAV, HERE + rover module is connected to the flight controller GPS connector, telemetry module is connected to the TELEM interface.




During operation, please place the base station in an outdoor environment with sufficient sky coverage to obtain a good satellite signal. Place the base station on a stable and elevated platform, such as a tripod.



ii) Base Module setting using Mission Planner


Start with base module setup first. During the base station setup, the rover and the UAV do not need to be turned on.

Open the Mission Planner ground station software on your computer and go to the initial setup -> Optional Hardware -> RTK / GPS Inject page. You will see the following page:



Select the correct base module com port in the top left corner and click connect. In the SurveyIn Acc section, enter the absolute geographic accuracy that you expect your HERE + base station to achieve. In the Time column, enter the minimum survey time you expect. Click on Restart, the ground station will transfer the data you have entered to the HERE + base module, the base module will start a new round of surveying. You will see the following page:





During the survey process, the right box will show the current survey status:


- Position is invalid: base station has not yet reached a valid location;
- In Progress: survey is still in progress;
- Duration: The number of seconds that the current surveying task has been executed;
- Observation: the number of observations acquired;
- Current Acc: Absolute geographic accuracy that the current base station can achieve.

The green bar at the lower part of the Mission Planner page shows the satellites being detected and the signal strength related to each satellite.

The base station needs a certain amount of time to meet the accuracy requirements of your input. Testing shows that, in an open area without shelter, to achieve the absolute accuracy of 2m takes a few minutes; to reach the absolute accuracy of less than 30cm takes around an hour; to reach the accuracy of 10cm takes a few hours.


It should be noted that the absolute geographic accuracy of the base station here will affect the absolute geographic accuracy of the rover module without affecting the relative accuracy between the base station and rover. If your application does not require UAV with high absolute geographic accuracy, you do not need to set the base station's precision too high, resulting in long survey time. Even if the accuracy of the base station is 1.5 to 2 m, the position accuracy of the rover module relative to the base station can still reach centimeter level.


After the survey is complete, Mission Planner will display the following page:



In the RTCM box it shows that the base status indicator is green and both the GPS and Glonass satellite systems are green (if you want to change the satellite system, refer to the following section). The box on the right says Position is valid.

To store the current location in the Mission Planner: Click Save Current Pos, enter a name in the dialog box, and click OK. As shown below, you can see your saved location in the list. Click the Use button for the location you saved. The base station will enter the fixed mode and the status will show Using FixedLLA. In the future, if you set the base station in the same location, you do not need to conduct survey again, just click the Use button that corresponds to the location you have saved.






iii) Rover Module and Flight Controller Setup

After the base station is set up, you can turn on the UAV. Using the same Mission Planner to connect the telemetry module, the base station data will be transmitted through telemetry module to the HERE + rover module on the UAV. In the Mission Planner main page, you can see the current GPS status displayed as RTK Float / RTK Fixed / 3D RTK, indicating that the positioning of the UAV has entered the RTK mode. RTK Float is a floating-point solution; RTK Fixed is a fixed solution. RTK Fixed mode has a higher accuracy and requires better signal strength. 3D RTK is unified saying of RTK Float / RTK in the Mission Planner Chinese version.




b) Use U-center for live data recording/replaying

One function of the U-center is to record the base / rover module data for later analysis. Firstly, when the base or rover module is already connected to U-center (in the same way it is connected when updating firmware), click the following bug icon to turn on the debug message:




Then, click into View -> message view -> UBX -> RXM -> RTCM (RTCM input status), right click to enable message.



Finally, click on the red recording icon on the upper left corner of the interface (shown below), select an address to save the recording, click OK, the recording will begin. When recording is stopped, the recording will appear in the previously saved address.



To play the recorded data, click the green play icon, select a playback speed, select the specified address of your stored data file, then the data will be played.



Secondly, the user input of survey-in accuracy requirement is too strict to achieve, or the base station has not yet completed the surveying process. Using U-centre for survey-in setup, please refer to section c) in this chapter.


b) [Check whether Rover receives base correction data\(Timeout\)](#)

After the base station enters the TIME Mode, it is necessary to transmit the RTCM data to the rover, for rover to enter RTK modes. Therefore, a real-time and efficient communication between rover and base station is necessary for good RTK positioning performance.

Check whether there is a delay in the data transmission between the mobile station and the base station, connect the rover module to U-center (or replay the data log to inspect a previous operation). Go to Messages view -> NMEA -> GxGGA directory to see Age of DGNSS Corr parameters. This parameter represents the time at which the rover did not receive the base station data. In the case of the default base station message frequency 1HZ, if this parameter exceeds 1s, there is a certain delay in the data transmission.

c) [Set Survey-in/Fixed mode for base station](#)

Similar to Mission Planner RTK Inject page, U-center can also be used to set the base station survey-in time and accuracy. Enter the Messages view option, UBX's CGF menu, enter the TMODE3 tab. Select 1.Survey-in under the Mode drop-down option, and set the survey time (and the minimum time required for the base station to survey). The survey-in current status can be viewed in the NAV-> SVIN page in Message View.




The base station can also be set to Fixed Mode. When the base station's current precise geographic coordinates are known, the coordinates can be entered directly into the base station, which saves the time required for surveying. In the TMODE3 page, select Fixed mode in the drop-down list, and then enter the precise known base station coordinates.


After setting the survey or fixed mode, click the Send button at the bottom left of the page to transfer the modified data to the base station.

d) Use Beidou/GLonass

The uBlox 1.30 firmware uses the GPS + GLONASS navigation system for location services by default. If you want to change to GPS + Beidou navigation system, you need to enter the Messages view -> UBX -> CGF -> GNSS directory, cancel the tick on GLONASS Enable option, and then check the Beidou Enable option. After the selection, click send to complete the change.



To save the current settings, go to the Messages view -> UBX -> CFG (Configuration) page and click the Save current configuration option, then click Send (as shown below).




Note: Base station and rover should use the same navigation system configuration, or rover will not be able to enter RTK modes.

e) Base module I/O port and protocol setup

UBlox M8P chip supports a variety of input and output protocols, including USB, UART, I2C and so on. The HERE + base station module uses the USB port for data communication and RTK outputs. If you need to confirm the current settings, go to the Messages view -> UBX ->

CFG -> PRT directory and select 3-USB in the Target field. The correct input and output protocols are shown below:




If you want to use more output protocols (such as UART), you can also select the output protocol and a specific message combination on this page. If you want to set a string of specific messages to output under a variety of protocols, you can go to the Messages view -> UBX -> CGF -> MSG directory, select a specific message, and then check the type of protocol you want to output.

To save the current settings, go to the Messages view -> UBX -> CFG (Configuration) page and click the Save current configuration option, then click Send.

f) Change Rover module output rate

By default, the output frequency of the position information by the rover module is 1HZ. If you need to speed up the position output frequency, you can enter the Messages view -> UBX -> CGF -> RATE directory, change the Measurement Period. For example, the measurement period is changed to 200 ms and the measurement frequency will be increased to 5 Hz.




To save the current settings, go to the Messages view -> UBX -> CFG (Configuration) page and click the Save current configuration option, then click Send.

4) Change Base Antenna and Testing

HERE + base module antenna is a Taoglass antenna. Users can select different antennas according to their needs and connect them to base module. We have conducted a test of three different antennas in an outdoor environment, where three antennas at the same time, same location were connected to the HERE + base station, data were logged using U-centre recording function. It should be noted that the following data are not sufficient to give a comprehensive conclusion about which antenna is better, but the user can use the following methods to test, compare different antennas to find the one more suitable for their application.

Test Antenna A :




Test Antenna B :




Original Antenna :




Base status with Antenna A at TIME Mode:




Base status with Antenna B at TIME Mode:




Base status with original antenna at TIME Mode:




Satellite signal comparison for each satellite:



Number of satellites reception above 40 with antenna A: 12 satellites



Number of satellites reception above 40 with antenna B: 13 satellites



Number of satellites reception above 40 with original antenna: 14 satellites

