



# Magic Lantern 0.2.1

for Canon 550D, 60D, 600D and 500D

## User's Guide

<http://magiclantern.wikia.com/unified>

July 7, 2011

Magic Lantern is an open (GPL) framework for developing enhancements to the amazing Canon 5D Mark II and 550D/T2i digital SLRs. Magic Lantern is being [developed](#) by a small team, helped by a very enthusiastic and respectful [user community](#).

**Initial version by** [Trammell Hudson](#) (original author and lead of Magic Lantern project)

**Crypto tools and firmware analysis by** [Arm.Indy](#), [AJ](#)

**Main developer for 550D and 60D cameras:** [Alex](#)

**550D/1.0.9 port by** [Arm.Indy](#)

**60D port by** [Arm.Indy](#), [Jason](#), [xaos](#), [SztupY](#), [Alex](#)

**600D port by** [Arm.Indy](#), [Vincent Olivier](#), [Alex](#)

**500D port by** [Chuchin](#), [AlinS](#), [Coutts](#)

**Patches by** [piersg](#), [nandoide](#), [stefano](#), [trho](#), [deti](#), [tapani](#), [phil](#), [RoaldFre](#), [Colin Peart](#), [cpc](#), [msi](#), [robotsound](#), [maclema](#), [adijiwa](#)

**Card tools by** [Pel](#), [Zeno](#), [lichtjaar](#)

**Cropmarks by** [CameraRick](#), [Robert](#), [bwwd](#), [turbincarpus](#), [Dremelv21](#), [similaar](#)

**Tutorials by** [sawomedia](#), [Chung Dha](#), [Dave Dugdale](#), [Malcolm Debono](#) [MediaUnlocked](#), [Jeremy](#), [Lauren Stevens](#), [Shayne35mm](#), [Mordy Gilden](#), [Ryan Sauv ](#), [Renny Hayes](#), [Daniel](#), [Dod3032](#), [3615geek](#), [CineDigital.tv](#), [jeveuxdoncjevilm ](#)

**Magic Lantern logo by** [Joseph](#)

Thanks to all the users who [provided feedback](#), [reported bugs](#), and supported the Magic Lantern project by [donations](#)!

Also, thanks to [CHDK team](#) and all the [contributors and donors for the 5D2 Magic Lantern](#)!

Magic Lantern is being developed by independent film makers in our spare time and at risk to our beloved cameras. We hope that it saves you time and aggravation on set, and we'd appreciate your support. You can help by [donating via PayPal](#), or through equipment donations. You can also [contact me \(Alex\) via email](#). Thanks!

[Donate](#)

## Features

- Audio: [disable AGC](#) and digital filters, [audio meters](#), [manual audio controls](#), selectable [input source](#) (internal, internal+external, external stereo, [balanced](#)), [audio monitoring](#) via USB.
- Exposure helpers: [zebras](#), [false color](#), [histogram](#), [waveform](#), [spotmeter](#).
- Focus tools: [focus peaking](#), [zoom while recording](#), [trap focus](#), [rack focus](#), [follow focus](#), [focus stacking](#), [focus graph](#), [zoom in Face Detect mode](#).
- Movie helpers: [Bitrate control](#) (QScale or CBR), [movie logging](#) (Exif-like metadata), [auto-restart](#) after buffer overflow or 4 GB limit, [time remaining display](#), [clean LiveView display](#) without any overlays, [change movie position](#) on the mode dial.
- [Cropmark](#) images: user-editable overlays to assist framing and composition.
- Fine control for [ISO](#), [Shutter](#), [Kelvin white balance](#) and other [image settings](#).
- Remote release with [LCD face sensor](#) and [audio trigger](#), without extra hardware.
- Bracketing: [exposure bracketing](#), [focus stacking](#).
- Timelapse: [intervalometer](#) (for photos and movies), [silent pictures](#) without shutter actuation; integration with bracketing.
- Astro- and night photography: [bulb timer](#) for very long exposures (up to 8h).
- Info displays: [focus and DOF info](#), [CMOS temperature](#), [shutter count](#), [clock](#).
- For strobists: [flash exposure compensation](#) from -10 to +3 EV.
- Power management: [Turn off display](#) in LiveView mode; quickly adjust [LCD backlight level](#).
- Fun stuff: [slit-scan pictures](#).

## Important notes

- If you have a bootable SD card and have the DISKBOOT flag set in the camera (which the installer does), and you do not have an AUTOEXEC.BIN file on the card the camera **WILL NOT BOOT!** It will hang and not wake up until the battery is removed.
- If you encounter a “locked up” camera, **quickly remove the battery**. Otherwise the ARM might be in a tight-loop and get very hot, very quickly. Your battery will run down and your LCD might show some discoloration.
- When in doubt, remove the battery and reboot.
- **And, remember that this software can damage or destroy your camera.**

# Contents

<b>Features</b>	<b>2</b>
<b>Important notes</b>	<b>2</b>
<b>FAQ</b>	<b>7</b>
How do I erase all the images without removing ML? . . . . .	7
How do I record more than 12 minutes? . . . . .	7
Can I record more than 30 minutes / 4 GB continuously? . . . . .	7
How do I get exposure times longer than 30 seconds? . . . . .	7
How do I see shutter counter / CMOS temperature? . . . . .	7
Do I have to adjust ISO/shutter/aperture/WB from ML menu only? . . . . .	7
Does ML eat batteries faster, or cause overheating? . . . . .	7
Why the audio is so quiet after disabling AGC? . . . . .	8
Why does the camera take pictures when pressing the shutter half-way? . . . . .	8
Can the intervalometer be more accurate? . . . . .	8
My camera freezes and I have to remove the battery, or saves corrupted files. Why? . . . . .	8
Why feature X doesn't work properly? . . . . .	8
<b>Known issues</b>	<b>8</b>
<b>Keyboard shortcuts</b>	<b>9</b>
LCD sensor shortcuts . . . . .	9
Flash button shortcuts . . . . .	9
Misc shortcuts . . . . .	9
<b>Magic Lantern menu</b>	<b>10</b>
Audio . . . . .	10
Audio Meters: ON / OFF . . . . .	10
Analog Gain (dB) . . . . .	10
L-DigitalGain and R-DigitalGain (dB) . . . . .	10
AGC: ON/OFF . . . . .	11
Input source . . . . .	11
Mic Power: ON/OFF . . . . .	11
Monitoring-USB: ON/OFF . . . . .	12
Output volume (dB) . . . . .	12
LiveV . . . . .	12
Global Draw: ON/OFF . . . . .	12
Histo/Wavefm: ON/Luma/RGB for histogram, OFF/Small/Large/Fullscreen for waveform . . . . .	12

Zebras: OFF/Luma/RGB, lo_level..hi_level	12
False color	13
Cropmks(x/n)	13
Ghost image: OFF / Centered / Left / Right	14
Spotmeter: OFF / Percent / IRE	14
ClearScreen: OFF / HalfShutter / WhenIdle	14
Focus Peak: OFF/HDIF/MORE, threshold, color_mode	15
Magic Zoom: OFF/Zrec/Zr+F/ALW, Small/Med/Large, AFF/NW,NE/SE/SW	15
Split Screen: ON/OFF, zerocross	16
Movie	16
Bit Rate: FW default / CBR / QScale	16
BuffWarnLevel: 30% ... 100%	17
Movie Restart: ON/OFF	17
Movie logging: ON/OFF	17
MovieModeRemap: A-DEP / CA	18
Movie REC key: Default / HalfShutter	18
Time Indicator: OFF / Elapsed / Remain.Card / Remain.4GB	18
WB workaround: ON/OFF	18
Zebra when REC: Hide / Don't Hide	18
Force LiveView: OFF / Start & CPU lenses / Always	18
Force HDMI-VGA: ON/OFF	19
Shoot	19
HDR Bracket	19
Take a pic every X seconds / Record Y seconds, pause X seconds	20
Intervalometer: ON/OFF, Wait/NoWait	20
LCD Remote Shot: OFF/Near/Away/Wave	21
Audio RemoteShot: ON/OFF	21
Motion Detect: OFF / EXP / DIF	21
Silent Picture / Silent Pic HiRes / Slit-scan Pic	22
Bulb Timer: 1s..8h	22
Mirror Lockup: OFF / ON / Timer+Remote	23
Expo	23
ISO: 100-25600	23
WhiteBalance: 1500...12000	24
WBSHift G/M: Green 0..9 / Magenta 0..9	24
Shutter: 1/24...1/4000	24
Aperture: f/1.2...f/45.0	24
Light Adjust: OFF/ALO strong/HTP	24

PictureStyle	25
Contrast/Saturation: -4.4	25
Flash AEcomp: -10.3 EV	25
Focus	25
Trap Focus: ON/OFF	25
Stack focus	26
Focus speed	26
Focus delay	26
Follow Focus: ON / OFF	26
Focus dir	27
Focus A	27
Rack Focus	27
Focal Dist	27
Hyperfocal	27
DOF Near	27
DOF Far	27
How rack focus works	27
Tweaks	28
AF frame display: Show / AutoHide	28
LCD Sensor Shortcuts: ON/OFF	28
Auto BurstPicQuality: ON/OFF	29
Exposure Simulation: OFF / ON / Auto	29
After taking a photo: QuickReview / Hold→Play	29
Zoom in PLAY mode	29
HalfShutter in DLGs	29
Show cropmarks in: Movie mode / All modes	30
ISO selection	30
Swap MENU ↔ ERASE	30
LiveView Zoom: x5 / x10 / :-)	30
Debug	30
Draw palette	30
Screenshot (10 s)	31
Debug logging: ON/OFF	31
Spy prop/evt/mem	31
Dim display: OFF / after X seconds	31
Turn off display: OFF / after X seconds	31
Turn off GlobalDraw: OFF / after X seconds	31
Config	31

Config AutoSave: ON/OFF . . . . .	32
Save config now . . . . .	32
Delete config file . . . . .	32
DISP presets: 1..4 . . . . .	32
<b>Extra info displays</b>	<b>32</b>
Main shooting screen (outside LiveView) . . . . .	32
MENU→DISP . . . . .	33
LiveView . . . . .	33
<b>Power saving</b>	<b>34</b>
<b>Hidden settings</b>	<b>35</b>

## FAQ

### How do I erase all the images without removing ML?

Canon menu (Play) → Erase images → All images on card.

Notes:

- This will not remove files created by ML (like \*.LOG, \*.422, \*.SH). You will have to delete these files from PC.
- Formatting the card will remove ML from that card. If you did this, you will have to make the card bootable again and then copy ML files.

### How do I record more than 12 minutes?

There's no 12 minute limit. There's a 30 minute limit and a 4 GB limit, whichever comes first. You can either lower the [bitrate](#) or use [Movie restart](#).

### Can I record more than 30 minutes / 4 GB continuously?

You can use [Movie Restart](#), but you will lose a few seconds when a new file is created.

### How do I get exposure times longer than 30 seconds?

Use [Bulb timer](#) together with [LCD remote shot](#), [audio trigger](#) or [intervalometer](#).

### How do I see shutter counter / CMOS temperature?

- MENU → DISP (550D, 500D, 600D)
- Press INFO button a few times in photo mode, outside LiveView (60D)

### Do I have to adjust ISO/shutter/aperture/WB from ML menu only?

No, you can adjust them both from ML menu or Canon user interface.

Note: custom settings which are not available in standard firmware (like Kelvin white balance on Rebel cameras) may not be displayed properly by Canon GUI.

### Does ML eat batteries faster, or cause overheating?

Yes and no, depending on what features you have enabled. For example, focus peaking, false colors, waveform, zebras (and maybe others) are CPU hungry. It can even reduce power consumption by turning off the LCD screen, or by letting you change the backlight level quickly. See [Power saving](#) for details.

## Why the audio is so quiet after disabling AGC?

You have to adjust the volume manually, the camera won't do it for you any more :)

## Why does the camera take pictures when pressing the shutter half-way?

[Trap focus](#) may be active.

## Can the intervalometer be more accurate?

Select the NoWait mode and it will be as accurate as the camera's realtime clock.

## My camera freezes and I have to remove the battery, or saves corrupted files. Why?

You may have an unstable build of ML. Upgrade to the latest one; if you still have problems, [report an issue](#).

## Why feature X doesn't work properly?

- Read the manual. In many cases you will find the solution.
- Try upgrading to the latest build. In some cases, downgrading to an earlier build will also help.
- Search the [Vimeo ML user group](#), the [issue tracker](#) and the [mailing list](#).
- If you still have problems, [report an issue](#) (if you've found a bug) or ask on the forums.

## Known issues

- First second of recorded audio may be very loud
- Sometimes, rack & stack focus simply refuse to work, and you need to restart your camera.
- Sometimes the menu gets overwritten by Canon's drawing routines, or flickers.
- External monitors are not yet fully supported (some functions may not work / display correctly). In order to use most Magic Lantern graphical overlays, (items from [LiveV](#) menu), you need to enable Force HDMI-VGA.  
With high-resolution HDMI displays, only cropmarks are known to work properly (from [LiveV](#) menu).
- Not all ML features are available on all compatible cameras.

## Keyboard shortcuts

### LCD sensor shortcuts

This feature is only available on 550D and 500D.

LCD sensor can be used as a simple remote (see [LCD Remote Shot](#) ) or as shift key (see also [SensorShortcuts](#) option).

- LCD sensor + UP / DOWN: adjust LCD backlight level.
- LCD sensor + LEFT / RIGHT in LiveView: adjust [Kelvin white balance](#).
- LCD sensor + Arrows: see [Follow Focus](#).
- LCD sensor + Zoom In: activates [Magic Zoom](#).

### Flash button shortcuts

This feature is only available on 550D and 500D.

- Flash in Movie mode (short press): toggle [False Color](#).
- Flash + UP / DOWN in Movie mode: adjust [audio](#) gain (volume for recording).
- Flash + LEFT / RIGHT in Movie mode: adjust [ISO](#).

### Misc shortcuts

- Half-shutter press at startup: loads vanilla firmware (does not load Magic Lantern). You may have to be in one of these modes: P, Tv, Av or M.
- ISO then LV: switch to Movie mode (from photo mode).
- ISO then DISP (550D) / Metering (60D): change current [display preset](#).
- Zoom In while recording: it does just that :) ([Magic Zoom](#))
- Half-shutter / \*: see [Display](#), [Trap Focus](#), [Silent Picture](#), [Bulb timer](#), [Movie REC key](#).
- MENU while recording will clear the screen and force a redraw of ML elements.
- SET in LiveView: center AF area (the little rectangle).
- MENU → DISP: display extra info like [shutter count](#) and [CMOS temperature](#).
- Q followed by SET, while *ISO speed* dialog is active: go to [ISO](#) item in ML menu.
- Q (550D) or Unlock (60D) in Play mode: draw the following items from [LiveV](#) menu: zebra, false color, histogram, waveform, spotmeter and cropmarks.
- LV button in PLAY or QuickReview mode: create a transparent overlay from current image. You can then move the overlay around with arrow keys in LiveView mode. To deactivate the overlay, go to PLAY mode and back without pressing LV on a new image.

## Magic Lantern menu

Press ERASE button to show the menu; use the arrow keys to navigate.

To change values, use SET, PLAY and Q. For most menu items, you can:


- press SET to change values forwards
- press PLAY to change values backwards
- press Q to invoke a special action (see the help text or the on-screen hints)

Complex menu items may use different actions for these 3 keys. Please see the documentation of the particular menu item you want to use.

In photo mode, outside LiveView, you can use the wheel(s) to navigate in ML menu. Press Zoom In button to activate edit mode and change values of a menu item with the wheel (experimental).

Press the DISP or INFO button to get help about a particular menu item.

## Audio



[Video:Ryan's T2i Tips and Reviews - Onboard Mic vs. ATR-3350 Lav vs Rode VideoMic](#)

Manual audio controls.

### Audio Meters: ON / OFF

Draw the audio meters or not. This setting takes effect only in movie mode.

Audio level scale is from -40dB to 0dB.

### Analog Gain (dB)

Gain applied to both inputs in the analog domain - intended as mic-type preamp, but always preferable to digital gain (unless you want different gain or run out of analog).

### L-DigitalGain and R-DigitalGain (dB)

Digital gain applied separately to the L and R channel.

## AGC: ON/OFF

Enable/disable Automatic Gain Control. AGC is applied only in digital domain (i.e. it overrides digital gains, but you can still adjust analog gain).


Disable this setting to prevent hiss noise when recording silence.

## Input source

Audio input source for recording:

- **internal mic**
- **L:int R:ext**
- **external stereo**
- **L:int R:balanced** (internal mic on Left, external mic on Right from both external pins as balanced audio)
- **Auto int/ext:** camera detects if a mic is plugged in. Int is dual mono, ext is stereo.

Canon Balanced Mic to Female XLR Cable Pinouts



"Balanced audio allows for very long cable runs without interference. Usually balanced mics have three pin XLR connectors and it is very easy to put together an XLR to Canon mic input cable. Balanced allows us to use such pro mics with our little Canons and this is a very welcome surprise for audio guys." ([source](#))

## Mic Power: ON/OFF

This is required for internal mic and certain types of external mics, but it reduces input impedance. See [AK4646 datasheet p.31](#) and the [Mic power control](#) thread.

- **ON:** input impedance is 2 k $\Omega$
- **OFF:** input impedance is 30 k $\Omega$

This setting is always ON when input source is either internal mic or L:int R:ext.

## Monitoring-USB: ON/OFF

Audio monitoring with headphones, via USB port.

To use this feature, you may use a modified USB - RCA cable or a USB - jack adapter. See [Audio monitoring HOWTO on Vimeo group](#) for details.

## Output volume (dB)

Volume for audio monitoring. It does not have effect on the internal camera speaker.

## LiveV



LiveView overlays: histogram, zebras, cropmarks, spotmeter, focus peaking, false color...

## Global Draw: ON/OFF

Enable/disable drawing extra graphics elements (zebra, cropmarks, histogram, waveform, false color, spotmeter, audio meters, ML shooting info...).

Tip: use this setting to quickly turn them off.

## Histo/Wavefm: ON/Luma/RGB for histogram, OFF/Small/Large/Fullscreen for waveform

Shows the distribution of image brightness levels with:

- a histogram plot (Luma or RGB, toggle with SET)
- a waveform plot (toggle with Q)

## Zebras: OFF/Luma/RGB, lo\_level..hi\_level

Enable/disable zebra stripes. which indicate overexposed or underexposed areas.

Modes:

- Luma: zebras are computed from Y channel only; overexposure is red, underexposure is blue.
- RGB: overexposure zebras are computed from RGB channels; underexposure zebras are computed from Y. Clipped channels are displayed in the opposite color (i.e. clipped red displayed as cyan, underexposed displayed as white...).

Keys:

- SET: toggle between OFF/Luma/RGB
- PLAY: change threshold for underexposure (blacks)
- Q: change threshold for overexposure (whites)

Brightness values are between 0 and 255. A threshold equal to 0 will disable zebras for underexposure, and 255 will disable zebras for overexposure.

### False color

This is a tool for evaluating the exposure. It shows different luma (Y) levels using a color map. You can press Q to select one of the following color maps:




In Movie mode, you can toggle False Color with a short press of Flash button.

### Cropmks(x/n)

Select cropmarks (cycle between them).

There are 4 predefined cropmarks in the zip archive:

- 16:9 black bars
- HD with Title & Action Safe
- Cinemascope
- Fisheye for stills framing with Samyang/8mm.



Notes:

- By default, cropmarks are displayed only in Movie mode. You can enable cropmarks in photo modes from the [Tweaks](#) menu, see [Show cropmarks in: Movie mode / All modes](#).
- If you use custom cropmarks, place them in CROPMKS folder on your SD card and give them short 8.3 names. The number in parenthesis Cropmks (x/n) shows the selected cropmark number and the number of detected cropmarks. You can place at most 9 cropmarks on the card.
- An exclamation mark (!) displayed in the menu means there was an error loading the cropmark image.

- Get more cropmarks created by Magic Lantern users [from the ML cropmark repository](#).
- See [Cropmarks](#) for how to create custom cropmarks.
- Tip: use Debug→Screenshot to get a bitmap with the correct palette.

### **Ghost image: OFF / Centered / Left / Right**

Shows a transparent overlay which can be created from any image in Play mode.  
To select the image, go to Play mode and press the LiveView button.

### **Spotmeter: OFF / Percent / IRE**

Measure brightness in the center of the frame, and display it as a percentage or IRE value.

Keys:

- SET: enable/disable spotmeter
- Q: change measurement unit:
  - Percent (0..100%)
  - IRE -1..101 (formula used by AJ, which maps 0-255 brightness levels to approx. -1..101 IRE)
  - IRE 0..108 (formula proposed by Piers, which maps 16-235 brightness levels to 7.5-100 IRE)

Note: when using low-contrast picture styles (like Marvels Cine or Superflat), the brightness might not reach the extreme values, even under strong under/over-exposure. This is OK.

### **ClearScreen: OFF / HalfShutter / WhenIdle**

Clear bitmap overlays from LiveView display.

- **HalfShutter:** Hold the shutter half-pressed, or the \* button, or DOF preview for around 1 second, and this will clear all the overlays from the Live View display (audio, zebra, crops, shutter speeds...). It allows you to compose the picture without any extra distractions.  
This works best when autofocus is assigned to the \* button (from Custom Functions, set CFn.9 to 1: Shutter/AE lock button = AE lock/AF).
- **WhenIdle:** In this mode, all the overlays are erased from the screen (100% clean display) when the camera is idle.  
This feature allows you to use an external HDMI recording device.  
The overlays (zebras & friends) will be back when you enter the Q menu or when you press the shutter half-way, and then disappear.

### Focus Peak: OFF/HDIF/MORE, threshold, color\_mode

Experimental focus peaking, see [Focus Assist](#) and [discussion thread](#).

- SET: toggle between available algorithms or turn the setting off
  - HDIF: looks at difference between adjacent pixels. Detects horizontal edges only. It is fooled by high-contrast, out of focus edges.
  - MORF: looks for fine detail lost by morphological opening and closing (which is a kind of blurring). It handles high-contrast OOF edges well, but is very sensitive to ISO noise.
- Q: adjust percentile threshold, between 0.1% and 5%.
- PLAY: select color mode
  - one of R, G, B, C, M, Y (a single color)
  - cc1: color coding 1 (show edge detection threshold as color, a single color for the entire frame; warmer = higher)
  - cc2: color coding 2 (show edge strength as color for every pixel)

### Magic Zoom: OFF/Zrec/Zr+F/ALW, Small/Med/Large, AFF/NW,NE/SE/SW

This function enables zoom while recording. It is similar to [Magic Circles](#) from AJ builds, but here it's square.

When ML believes you have achieved perfect focus, Magic Zoom borders will become green.

Modes (change with SET):

- OFF
- Zrec: triggered by Zoom In button, pressed either while recording or while the LCD sensor is covered
- Zr+F: triggered by Zoom In button while recording, and also by rotating the focus ring (only on lenses which report focus distance, or if you use [follow focus](#) / [rack focus](#)).
- (\*): triggered by Zoom In button (overrides Canon's default zoom modes). To bypass magic zoom, cover the LCD sensor or press both zoom buttons at the same time.

Size / magnification (change with PLAY):

- Small (150x150)
- Medium (250x200)
- Large (500x300)
- Small X2 : small with x2 magnification
- Med X2 : medium with x2 magnification

Positions (change with Q):

- AFF: moves with the AF frame (the little rectangle)
- NW, NE, SE, SW: the zoom overlay is placed in one of the 4 corners. The zoomed area is still linked to the AF frame.

Magnification (linear):

- while recording FullHD: around 2.4x.
- while not recording: around 1.5x.
- x2 setting doubles the magnification, but it does not add any extra detail (just doubles the pixels). It may be easier to see, though.

Notes:

- On HDMI displays, it only works well during recording. It does not work on SD (RCA) displays.
- It does **not** work in certain video modes (e.g. 720p) when not recording.
- [Zebras](#), [focus peaking](#) and [false color](#) are disabled automatically when the zoom overlay is active.
- Half-pressing the shutter will hide the zoom overlay.

### Split Screen: ON/OFF, zerocross

When the image is out of focus, Magic Zoom window looks similar to a split focusing screen commonly used in old film cameras.

This is just an alternate display for [focus graph](#). It can't detect whether you are focusing too far or too close, and the display is only accurate a few seconds after you turn the focus ring and cross the perfect focus point.

Zerocross option will reverse the split direction whenever you achieve perfect focus.

## Movie

```

Audio LiveV Movie Shoot Expo Focus Tweak Debug Config (1)
X Bit Rate : FW default
A BuffWarnLevel : 70%
G Time Indicator : Remain.Card
G Movie Logging : ON
X Movie Restart : OFF
X MovieModeRemap : OFF
X Movie REC key : Default
G WB workaround : ON(save WB in cfg)
G Zebra when REC : Show
X Force LiveView : OFF

H.264 bitrate. Use with care! (Q/PLAY): change value.

```

Functions specific to movie mode.

### Bit Rate: FW default / CBR / QScale

Controls H.264 bitrate used for video recording.

Modes:

- **FW default:** default bitrate used by Canon firmware (CBR, around 45mbps in 1080p, including sound).
- **CBR:** constant bitrate. You specify a factor for multiplying default video bitrate, between 0.1x and 3x. CBR 1x is equivalent to FW default. The implementation uses variable QScale, displayed near the recording dot.
- **QScale:** constant quality, variable bitrate (VBR). Available values: -16 ... +16. Lower numbers mean higher bitrates.

Keys:

- Change mode with **SET**
- Change numeric value with **Q** and **PLAY**

Notes:

- There is a bitrate / QScale display near the red recording dot, updated every second.
- Slower cards will not handle high bitrates, and recording will stop automatically if you try to use them. This includes certain cards labeled as Class10.
- In QScale mode, bitrate varies a lot with frame complexity, and you have no direct control over its value.
- In CBR mode, on scenes without a lot of details, QScale will not go further than -16, and bitrate will be lower than requested. As soon as frame complexity increases, the bitrate will increase too, and video may stop recording. In this case, bitrate meter will be displayed in red.
- You can't change this setting during recording.

See [Bit rate](#) page for details.

#### **BuffWarnLevel: 30% ... 100%**

If buffer usage gets higher than this value, ML will display the buffer indicator in red and will pause all CPU-intensive graphics (almost everything from [LiveV](#) menu), which will allow movie recording tasks to use all available CPU power in order to avoid a possible buffer overflow.

#### **Movie Restart: ON/OFF**

While this setting is on, movie recording will restart automatically, unless stopped by you. There will be a few seconds skipped during restarting.

#### **Movie logging: ON/OFF**

If this setting is ON, Magic Lantern will write out a metadata file for each movie to MVI\_1234.LOG (numbered after the movie). The log file contains lens and exposure info, as well as a timestamp every time any of the parameters is changed during recording.

Log files are placed in the same folder as the movies: DCIM/100CANON/, 101CANON etc.

Tip: you can rename LOG files to CSV and import them in MS Excel.

### **MovieModeRemap: A-DEP / CA**

Changes movie position on the mode dial. You can swap movie mode with either A-DEP or CA.

Alternative: press ISO and then press LV.

### **Movie REC key: Default / HalfShutter**

This option enables you to start/stop movie recording by half-pressing the shutter button.

### **Time Indicator: OFF / Elapsed / Remain.Card / Remain.4GB**

When recording a movie, ML will display a small time counter in the upper right corner, which can be:

- Elapsed: duration of the current clip
- Remain.Card: estimated amount of recording time remaining on the card.
- Remain.4GB: estimated amount of recording time until reaching 4GB (or until filling the card, whichever comes first).

Unlike Canon's timer which assumes constant bitrate, ML timer assumes variable bitrate and works even if QScale is enabled. However, due to variations in bitrate, the estimated value will fluctuate a lot, and this is normal.

### **WB workaround: ON/OFF**

Workaround for remembering Kelvin temperature and WBShift G/M and B/A values in Movie mode.

If this setting is on, these values are stored in config file. They will be shared between movie and photo modes.

Note: WBShift B/A can be only changed from Canon menu in photo mode, but with WB workaround enabled, WBShift settings will take effect in Movie mode, too (and also in auto modes, as a side effect).

### **Zebra when REC: Hide / Don't Hide**

You can disable zebras during recording.

### **Force LiveView: OFF / Start & CPU lenses / Always**

Force LiveView in Movie mode (bypass the dialog saying *Press LV button to activate movie shooting*).

- Always: force LiveView even if you use an unchipped lens, or no lens at all. Be careful, you may get dust on the sensor while changing lenses.

- Start & CPU lenses: it will force LiveView at startup, regardless of the lens used. After this, it will only bypass the dialog when a chipped lens is attached (i.e. it will enter LiveView as soon as you attach a chipped lens).

### Force HDMI-VGA: ON/OFF

This option will force a low-resolution mode on HDMI displays (720x480), which:

- Avoids getting black screen when you start recording;
- Lets you use most items from [LiveV](#) menu (zebras, false color, histogram...)

## Shoot



Functions for stills shooting (some of them work for movies, too).

### HDR Bracket

AE Bracketing for HDR images and timelapses.

Select number of images with SET and step size with PLAY. To turn this off quickly, press Q.

In M mode, this function does shutter bracketing. In the other modes it does exposure compensation bracketing.

HDR images can be taken with:

- ML remote triggers: LCD face sensor & audio trigger.
- ML intervalometer (for HDR timelapse)
- Press the shutter. In this case, the first image will have the middle exposure (without EV compensation), and the 2-second self-timer will be used. Also, this mode only works with 3 images or more.

For best results, switch to manual focus and use relatively slow exposure times.

For each HDR picture set, Magic Lantern also writes a bash script for stacking the exposures with [enfuse](#) (version 4.x). The scripts are stored in DCIM/###CANON and are named after the first picture in set, e.g. if the HDR sequence is created from IMG\_1001.JPG ... IMG\_1005.JPG, the HDR script will be named HDR\_1001.SH and the resulting HDR image will be saved as HDR\_1001.JPG.

To run the HDR scripts on the computer, move the scripts and the JPGs in the same directory and run (for example):

```
bash HDR_1001.SH
```

or, for processing all the images at once:

```
for f in $(ls *.SH); do bash $f ; done
```

On Windows, you can use Cygwin or MSYS to run the scripts.

Don't forget to delete the scripts from the card; the camera won't delete them!

### Take a pic every X seconds / Record Y seconds, pause X seconds

Change the intervalometer settings (first setting appears in photo mode, second appears in movie mode).

There is also a mode named `Take pics like crazy`, which does exactly that. This is the best tool for killing your shutter.

### Intervalometer: ON/OFF, Wait/NoWait

#### Video:T2i Timelapse

Start/stop intervalometer.

- In photo mode, it takes a sequence of photos with a fixed rate or delay (toggle with Q):
  - `Wait`: intervalometer waits until the picture is taken and saved to card, then starts counting the time for the next picture (default, fixed delay with 1-second resolution).
  - `NoWait`: timer for next shot starts as soon as current shot was triggered (it does not wait for exposure to finish, nor for picture to be saved). This ensures precise timing between shots (fixed rate). If the total time required for taking a picture is larger than the interval between two shots, it will miss some frames.

The `Wait/NoWait` setting has no effect in movie, [HDR](#) or [bulb timer](#) modes.

- In movie mode, it takes a sequence of small videos
  - When `HDR Bracket` is active, each movie will be exposed according to the bracketing settings, and the duration of the movie will be multiplied by number of exposures.
  - To use the intervalometer in movie mode, make sure [Silent Picture](#) is OFF.

You can stop the intervalometer either from ML menu, or by pressing MENU or PLAY, or by changing the shooting mode. You can pause the intervalometer by holding the shutter halfway, or by opening ML menu.

Tips:

- Shoot in manual mode and switch the lens to MF.
- To save the shutter count when doing timelapses, enable [Silent Picture](#) or use the intervalometer in Movie mode.
- Do not use the intervalometer in LiveView with “noisy” mode (otherwise your shutter will wear twice as fast than outside LV).
- If the intervalometer can't be stopped (it may happen in crazy mode), turn the camera off or open the card door.

Power Saving:

- When not in LiveView, press DISP to turn the display off. You may also cover the LCD sensor with something.
- In LiveView, enable the [Turn off display](#) option. You also have to assign the focus on the \* button (otherwise the screen will wake up). ML will NOT turn off the sensor.
- While the intervalometer is running, the card led will blink once per second to let you know it's alive and kicking.

Note: ML will emulate half-shutter presses every second to prevent the camera from entering stand-by mode. You have to make sure it won't autofocus.

### LCD Remote Shot: OFF/Near/Away/Wave

Start/stop remote shutter release mode with the LCD sensor.

- ☉ **Near**: To take a picture, put your hand near the LCD sensor.
- ☽ **Away**: Picture is taken when you get your hand away from the sensor. You may combine this setting with [Mirror Lockup](#).
- ♫ **Wave**: Picture is taken after you wave your hand 3 times near the sensor. You can leave it on without interfering (too much) with normal shooting.

This feature is useful for avoiding camera shake.

In Movie mode, the Wave ♫ setting is able to start and stop recording movies. The other modes can only start recording (because it's too easy to stop recording by mistake).

### Audio RemoteShot: ON/OFF

Start/stop remote audio trigger. To take a picture (or start recording a movie), make some loud noise, for example, clap your hands or pop a balloon.

You can also start movie recording with this feature.

In photo mode, you can combine this option with the self-timer (may be useful for group or self pictures).

Be careful: this may trigger the shutter from the sounds made by camera (like focus beep or liveview switch).

### Motion Detect: OFF / EXP / DIF

Experimental motion detection.

- EXP: it only reacts to brightness (EXPosure) change in the middle of the Live-View image. Useful for large moving subjects which cause significant change in exposure.
- DIF: it computes the DIFference between last two frames A and B (luma channel only); it is useful for detecting smaller movements which do not change exposure. Trigger condition is:

$$\sum_{i,j} |A_{ij} - B_{ij}| > level$$

Detection time is somewhere between 200 and 300 ms according to [DataGhost's speed test](#); it's faster with silent pictures.

## Silent Picture / Silent Pic HiRes / Slit-scan Pic

This can take pictures in LiveView mode without moving the mirror. When enabled, it saves uncompressed YUV422 frames from the LiveView buffer when you press the shutter halfway.

- Make sure you don't have autofocus assigned to half-shutter press (put it on \* or turn it off)

Modes:

- Silent Picture: simple, low-resolution. Image resolution is usually around 1 or 2 MPix, and depends on the current mode (zoom or not, recording or not, and movie resolution). For almost-FullHD resolution (1720x974), choose FullHD to record a dummy movie. [Details here](#).
- Slit-scan Pic: this takes distorted images [like these](#). This mode is basically an extreme jello effect which can be used in creative ways.

Keys:

- SET: toggle modes (normal / slit-scan)
- PLAY/Q: toggle between:
  - Single/Burst/FullHD in normal mode
  - timing (number of clocks to skip after each line) in Slit-scan mode.

Silent picture setting is applied to [intervalometer](#) and [remote triggers](#) when used in LiveView mode.

Images are saved in DCIM/1xxCANON/ after the following rules:

- If intervalometer is OFF, silent pics are named after last picture / movie taken without this function (e.g. 1234-001.422). You are limited to 1000 silent pictures for each "noisy" picture.
- If intervalometer is ON, silent pics have names like 12345678.422.  
Tip: use File Numbering → Manual Reset from Canon menu to increase folder number (to sort them easier).

To convert a 422 image to JPEG on the PC, use [422-jpg.exe](#) (Windows and Wine) or [422-jpg.py](#) (all platforms, you need to install Python, PIL and numpy). Double-click it, then select a single 422 file, or click Cancel and select a folder with 422 files. You can also use this program in command-line.

Note: FullHD option will cause errors during playback; they are caused by dummy videos which were removed by ML, but camera thinks they are still there. After restart, the errors will disappear.

TODO:

- avoid that horizontal cut in pictures (vsync doesn't help and there's not enough RAM to buffer an entire image)

## Bulb Timer: 1s...8h

Very long exposures with Bulb mode and ML timer.

Bulb timer is started by half-shutter press, or by remote triggers / intervalometer.

Tip: you can cancel the exposure earlier by half-pressing the shutter button.


## Mirror Lockup: OFF / ON / Timer+Remote

Mirror Lockup.

Timer+Remote will auto-enable MLU under one of the following conditions (and disable it otherwise):

- self-timer mode is on (either 2 second or 10 second, but not continuous)
- [LCD Remote Shot](#) is in Away mode.

## Expo



Adjusting the exposure parameters. Most of these settings only work in Manual (photo and video), and some of them work in P, Av and Tv too.

### ISO: 100-25600

Fine-tuning for ISO, in 1/8 EV steps.

Possible values (not all values are accepted by all cameras):

0 (Auto), 100, 110, 115, 125, 140, 160, 170, 185, 200, 220, 235, 250, 280, 320, 350, 380, 400, 435, 470, 500, 580, 640, 700, 750, 800, 860, 930, 1000, 1100, 1250, 1400, 1500, 1600, 1750, 1900, 2000, 2250, 2500, 2750, 3000, 3200, 3500, 3750, 4000, 4500, 5000, 5500, 6000, 6400, 7200, 8000, 12800, 25600.

To get ISO values higher than 6400, turn on ISO Expansion from Custom Functions (CFn 1). To get ISO lower than 200, turn HTP off. In video mode, ISO only goes up to 6400. This is also true without ML.

To get only “round” ISO values, i.e. 100, 160, 200, 320, 400, 640, 800, 1250, 1600, 2500, 3200, 6400, 12800 and 25600, see [ISO selection](#).

In manual exposure modes (photo and video), press the Q button on this entry to set the ISO value automatically.

- When LiveView is active, a binary search algorithm is used; the search criteria is a good balance between overexposure and underexposure; search resolution is 1/8EV. If the contrast is very low, the histogram will be centered.
- When LiveView is off, ISO is set using the Auto ISO feature from Canon firmware, in 1EV steps.

To compute exact ISO values from 100 to 6400, assuming 1/8 EV steps, use this formula:

$$100 \cdot 2^{k/8}, \quad k = [0 : 48]$$

**WhiteBalance: 1500...12000**

Kelvin white balance. Extended range (\*) is only available in Movie mode and LiveView. For still pictures, Kelvin WB will be clamped to the native range, i.e. 2500...10000.

In LiveView, press the Q button on this entry to set the WB temperature using the center color as reference gray. The measurement area is 200x200 pixels, centered.

**WBShift G/M: Green 0..9 / Magenta 0..9**

Green-Magenta white balance shift. Useful for fluorescent lighting.

**Shutter: 1/24...1/4000**

Custom steps for shutter speed, in 1/8 EV steps.

Assuming 1/4000 is native, you can use the [EV definition](#) to compute all available shutter speeds between 30s and 1/8000, resulting:

$$1/4000 \cdot 2^{k/8}, \quad k = [135 : -1 : -8]$$

Assuming 30s is native, you will have:

$$30 \cdot 2^{k/8}, \quad k = [0 : -1 : -143]$$

The difference between results in these two cases is around 1.3%.

Values displayed by ML (rounded to 2 digits):

1/24, 26, 29, 31, 34, 37, 41, 44, 48, 53, 57, 63, 68, 74, 81, 88, 96, 110, 120, 130, 140, 150, 160, 180, 190, 210, 230, 250, 270, 300, 320, 350, 390, 420, 460, 500, 560, 600, 650, 710, 770, 840, 920, 1000, 1100, 1200, 1300, 1400, 1500, 1700, 1800, 2000, 2200, 2300, 2600, 2800, 3000, 3400, 3700, 4000, 4400, 4800, 5200, 5600, 6200, 6800, 7300, 8000.

In manual exposure modes (photo and video), press the Q button on this entry to set the shutter value automatically.

- When LiveView is active, a binary search algorithm is used; the search criteria is a good balance between overexposure and underexposure; search resolution is 1/8EV. If the contrast is very low, the histogram will be centered.
- When LiveView is off, the shutter value is computed with the help of Auto ISO feature from Canon firmware, in 1EV steps. This feature is still experimental and sometimes it does not work.

**Aperture: f/1.2...f/45.0**

Adjust aperture.

**Light Adjust: OFF/ALO strong/HTP**

Select the light adjustment algorithm:

- OFF

- Auto Lighting Optimizer (strong)
- Highlight Tone Priority.

## PictureStyle

Change picture style. You can see the effect on LiveView instantly.


## Contrast/Saturation: -4.4

Adjusts the contrast and the saturation of the current picture style.

## Flash AEcomp: -10.3 EV

Flash exposure compensation.

## Focus



## Trap Focus: ON/OFF

Takes a picture when the subject comes into focus. You need to set the to Manual focus (MF) and hold the shutter pressed halfway.

- Outside LiveView, it only works with lenses with chip.
- In LiveView it only works for photos, and it will take a picture when the focus indicator has (almost) maximum value on the [focus graph](#).

Notes for LiveView trap focus:

- You may have to turn the lens back and forth a few times in order to let ML compute the correct focus scaling factor for the current scene.
- If you move from a high-contrast scene to a low-contrast one, you will also have to wait a bit until the high-contrast data disappears from the focus graph.

## Stack focus

This selection will shoot a series of photographs with varying focus points. You can also call this “focus bracketing”. It is used in macro photography to assemble sharper final images by merging photos where each has a different focus point.

This function will also create scripts named like named FST\_1234.SH, which can be used for stacking the images with enfuse. See [Exposure bracketing](#) for details on how to use these scripts, and the [focus stacking section](#) from Enfuse reference manual.

Keys:

- SET: change the number of photos
- Q: change the focus step size
- PLAY: run the stack focus sequence

## Focus speed

Adjust speed for rack focus and follow focus, in focus steps.

## Focus delay

Delay between two successive focus commands. See [this article](#) for details.

## Follow Focus: ON / OFF

Very simple follow focus (like a rack focus controlled manually).

When this setting is enabled, it will change the default behavior of arrow keys, according to the following table:

Key	Speed		Direction		
LEFT	slow	1x	far	+	↶
RIGHT	slow	1x	near	-	↷
UP	fast	5x	far	+	↵
DOWN	fast	5x	near	-	↴

You can reverse the direction for these keybindings:

- Press Q to reverse the direction for LEFT/RIGHT keys (slow speed)
- Press PLAY to reverse the direction for UP/DOWN keys (fast speed)

[Video:Magic Lantern for Canon 550D - Rack Focus Tutorial](#)

## Focus dir

This is the direction the lens moves when pressing the camera's Zoom In button to set the focus start and end points.

### **Focus A**

This is end point of rack focus. To set, focus the lens with the Zoom In button, then press "Set".

The start point will be the point where you are before selecting "Rack focus" in the menu.

### **Rack Focus**

Triggers the rack focus operation that moves between the start and end focus points. After the move is complete pressing again reverses the move.

The following items are display only:

### **Focal Dist**

The distance to the focal point. Value is returned by most newer Canon lenses. If the lens does not report any distance information, 0 will be displayed and the DOF calculations will not be correct.

See also [Focus distance](#).

### **Hyperfocal**

The hyperfocal distance is the point of focus where everything from half that distance to infinity falls within the depth of field. This is the largest depth of field possible for the current f-number.

### **DOF Near**

The nearest distance in which objects appear in focus.

### **DOF Far**

The farthest distance in which objects appear in focus.

### **How rack focus works**

Now that you know what the buttons are about, here is how you make it work:

1. Pick the end point of rack focus by focusing on it (manually or with AF).
2. Open the Focus menu, go to Focus A and press Set to zero it out.
3. Pick the start point by focusing on it **from ML controls**. Do NOT use autofocus and do NOT focus manually from the lens ring.

To focus the lens, make sure it is set on AF and use one of the following:

- Option 1: choose Focus dir and hold on the Zoom In button while Focus menu is active.

- Option 2: enable [Follow focus](#), close the focus menu and focus with the arrows.
4. Select the focus speed. The number varies between different lenses and represents raw encoder steps for the focus motor.
  5. Next, start movie recording (you can do that while ML menu is active).
  6. Go to Rack Focus and press SET to start rack focus. You should see the rack focus commence and complete its cycle.
  7. To return to the beginning point, you can press SET again to return to that point, once again.

**Note:** the rack focus command may “stutter” while racking with some lenses, causing overshoot or undershoot of the desired position. This feature is still under development and should be more mature in a later version.

See also the description from the [5D2 ML User Guide](#).

## Tweaks



Miscellaneous settings.

### AF frame display: Show / AutoHide

Control the appearance of AF frame:

- Show: show the AF frame (just like the standard firmware)
- AutoHide: the AF frame is only displayed when you move it, and then it disappears after 1 second or so.

### LCD Sensor Shortcuts: ON/OFF

Enable the use of [LCD sensor](#) as an extra shift key. This function allows you to adjust [white balance](#), LCD backlight level, move the AF frame when [follow focus](#) is active, or trigger [Magic Zoom](#) when not recording.

To fully disable the [LCD sensor](#) in Magic Lantern, disable LCD auto off from Canon menu (Wrench 1). You need to do this if you are using a device which covers the LCD sensor (e.g. a loupe).

### **Auto BurstPicQuality: ON/OFF**

When enabled, it will temporarily reduce picture quality in burst mode in order to maintain a decent frame rate even when the buffer becomes almost full.

This function will reduce picture quality in the following steps:

- RAW+JPG → RAW → JPG Large Fine → JPG Medium Fine
- JPG Large Coarse → JPG Medium Coarse

### **Exposure Simulation: OFF / ON / Auto**

Exposure simulation (ExpSim) in LiveView display (for photo mode only).

- ON: LiveView display image reflects exposure of the final image.
- OFF: LiveView display image does not reflect the exposure, but may be useful for framing and checking focus.
- Auto: ExpSim is:
  - disabled during zoom (x5, x10 and MagicZoom), but only if shutter is not pressed halfway;
  - enabled otherwise.

When ExpSim is off, zebra, histogram, waveform and false color are not displayed.

### **After taking a photo: QuickReview / Hold→Play**

Image review behavior.

- QuickReview: just like in standard firmware
- Hold→Play: if you set Image Review:Hold in Canon menu, it will go to PLAY mode instead. This allows you to zoom in as soon as you take the picture (without having to press PLAY).

### **Zoom in PLAY mode**

Increase the speed of zoom function in PLAY mode.

- Normal: just like in standard firmware
- Fast: zoom on steroids

### **HalfShutter in DLGs**

- SET: Half-shutter press in almost any Canon dialog window /box will **activate** the current selection. This helps you change settings faster in photo mode. It works by emulating a SET button press when GUI\_STATE property is equal to PLAYMENU, which includes dialogs like WB, AF, pic style, pic quality, Canon menu and submenus and others.
- Cancel: default firmware behavior (i.e. **cancel** the current selection on half-shutter press).

## Show cropmarks in: Movie mode / All modes

It does just that. See [Cropmark](#) for more info.

## ISO selection

- All values: use all available ISO speeds, in 1/8 EV steps
- 100x, 160x: use only native ISOs (multiples of 100) and ISO values with lower digital gain (multiples of 160).

## Swap MENU ↔ ERASE

Swaps MENU and ERASE buttons. This feature allows one-handed navigation in ML menu on 60D, but will have to use MENU button to delete the pictures.

## LiveView Zoom: x5 / x10 / :-)

Control the zoom feature in LiveView. Change x5/x10 settings with PLAY and toggle :- ) with SET.

- x5: only x5 zoom will be available (disables x10 zoom)
- x10: only x10 zoom will be available (disables x5 zoom)
- x5x10: both settings available (Canon default)
- :- ) Enable zoom in Face Detection mode

## Debug



```
Screenshot in 0 seconds
Audio LiveV Movie Shoot Expo Focus Tweak Debug Config (1)
▶ Draw palette
▶ Screenshot (10 s)
× Debug logging : OFF, Q=dump
× Spy prop/evt/mem (s/d/q)
▶ Don't click me!
● UnifLoop (experim): Auto

Take a screenshot after 10 seconds [SET] or right now [Q].
```

Functions for troubleshooting, development, and possibly unstable features.

Some items from this menu may not be available in release builds; you can uncomment them from debug.c and create a custom autoexec.bin.

### Draw palette

Tests the 8-bit bitmap palette, which is used for video overlays. See [VRAM](#).

## Screenshot (10 s)

Print screen after 10 seconds. It saves a BMP file for the overlays and a 422 file (silent picture) for the LiveView image. The BMP does not contain transparency data. You can combine the two files in GIMP or other image editing programs.

A small timer is displayed. After 5 seconds, it won't be updated any more (which lets you remove it from the screenshot by triggering a redraw).

## Debug logging: ON/OFF

When enabled, the camera stores a log which contains DebugMsg output. Press Q to dump the log to a file on the SD card. Disabling this setting might save a few CPU cycles.

See [Debugging Magic Lantern](#) page.

## Spy prop/evt/mem

- prop: display property changes in real-time. See [Properties](#).
- evt: Display GUI events in real-time. See [GUI\\_Events/550D](#).
- mem: Display memory addresses which change, but not those which change like mad. Useful for detecting interesting [Memory Addresses](#) inside the camera RAM (like sensor & button locations).

## Dim display: OFF / after X seconds

In LiveView, if the camera is idle, Magic Lantern will reduce the LCD backlight level to minimum in order to save power.


## Turn off display: OFF / after X seconds

In LiveView, if the camera is idle, Magic Lantern will turn off the built-in LCD display in order to save power.

## Turn off GlobalDraw: OFF / after X seconds

In LiveView, if the camera is idle, Magic Lantern will turn off [Global Draw](#) in order to save power.

## Config



Magic Lantern saves its settings in a configuration file named [magic.cfg](#). This menu lets you customize how these settings are saved.

### Config AutoSave: ON/OFF

If enabled, settings are saved automatically to `magic.cfg` whenever you change a setting in ML menu.

Config saving process will take place as soon as you close the menu.

### Save config now

Saves ML settings to `magic.cfg`.

### Delete config file

Deletes `magic.cfg`, which will restore ML default settings at next boot.

Note: This item will disable Config AutoSave for the current session, in order to make sure the config file won't be re-created when you close the menu.

### DISP presets: 1..4

This feature lets you use up to 4 display presets for the settings in the [LiveV](#) menu.

On the top bar, you will see DISP 0, 1, 2 or 3. Each of those is a preset for the settings in LiveV menu. So you can, for example, configure DISP 1 with false colors, DISP 2 with zebras and focus peaking, and DISP 3 with clear display.

This menu item sets the maximum number of available DISP presets. To disable this feature, set the number of presets to 1.

To change the presets, press:

- on 550D/500D: ISO followed by DISP;
- on 60D: the Metering button.

## Extra info displays

### Main shooting screen (outside LiveView)



- Clock (bottom of screen)
- ISO value in finer increments (above Canon's ISO display)

- Trap Focus status (near MF icon)
- Kelvin temperature (in the white balance box)
- WB shift values for BA and GM
- [HDR](#) setting (under battery icon)
- [MLU](#) setting (under Q icon)
- [LCD remote](#) status icon: ☒ ◉ W

## MENU→DISP

```
Shutter Count: 24574
CMOS Temperat: 158
Lens: EF50mm f/1.8 II
```

- Shutter counter. Only counts pictures taken, not LV switches or quick focus attempts.
- CMOS temp: temperature of the CMOS sensor (EFIC temperature), in raw units. Before, this was in the Debug menu.
- Lens name

This info also appears on error displays (e.g. ERR 70).

## LiveView

- Bottom bar (displayed only when Canon bottom bar is hidden):
  - Current shooting mode
  - Lens focal length and aperture,
  - [shutter](#), [ISO](#), [white balance](#), WB shift
  - [Focus\\_distance](#)
  - Exposure compensation (codenamed AE)
- Top bar (displayed only when audio meters are not shown):
  - Clock
  - Current [display preset](#)
  - Picture quality setting
  - CMOS temperature
  - Number of pictures remaining (estimated)
  - Free space remaining, in GB (may be incorrect on certain cards)
- In the middle of the screen:
  - [Spotmeter](#)
- Around the recording dot:

- [Time remaining display](#)
- [Bitrate](#) info (instant and average bitrate, and qscale factor)
- Buffer indicator (see also [BuffWarnLevel](#))
- Left side:
  - Status for [trap focus](#) / [follow focus](#).
- Top side:
  - [Audio meters](#) and audio input source for each channel
  - [LCD remote](#) status icon: ⊗ ⊙ ∞

- **Focus Graph**

This item is displayed when you enable [Trap Focus](#).

It draws a small graph which shows the *amount* of focus in the AF frame (the little rectangle), over the last few seconds. Focus computation is done by Canon's autofocus algorithm.

Since the function which measures the amount of focus is heavily influenced by other factors (like contrast and exposure), ML attempts to normalize the value.

If you are focusing manually, try to position the lens such as you get a local maxima on the focus graph.

## Power saving

Magic Lantern can help you maximize battery life while shooting, which also results in reduced overheating.

If you enable many CPU-intensive functions for [LiveV](#) menu, the battery will drain a bit faster.

To save power, you may:

- [Turn off display](#) in LiveView mode
- Dim the display when idle
- Turn off [Global Draw](#) when idle
- Quickly adjust [LCD backlight level](#)

Power consumption in movie mode, for Canon 550D, idle, 24p (approximate figures derived from [this test](#)):

Item	Current (approx)
Camera body (without lens), LCD off	360 mA
Lens (Tamron 17-50/2.8)	20 mA
LCD backlight at level 1	40 mA
LCD backlight at level 7	100 mA

... continued on next page

Item	Current (approx)
Magic Lantern with GlobalDraw off	around 10 mA
Zebras	around 15 mA
Focus peaking	maybe 25 mA (not tested)

NTSC		PAL	
Mode	Current	Mode	Current
1080 30p	480 mA	1080 25p	450 mA
1080 24p	440 mA	1080 24p	440 mA
720 60p	520 mA	720 50p	490 mA
480 60p	520 mA	480 50p	490 mA
crop 60p	430 mA	crop 50p	420 mA

Power consumption [varies with the frame rate](#). The table above shows the difference between video modes. The test was done on a 550d with ML, body cap only, movie standby, lcd brightness 4, default settings, i.e. no magic.cfg at startup.

## Hidden settings

The configuration file (MAGIC.CFG) lets you tweak various hidden settings using a simple text editor (Notepad, gedit, vi...), and is also used to save Magic Lantern configuration from the GUI menu.

These settings can not be changed from the ML menu:

```
# if set to 1, disable the bootdisk flag.
# This does the same thing as Debug→Autoboot menu item.
# Only for advanced users!!!
magic.disable_bootdiskf = 0

# Delay between clearing the overlay in Clear Preview mode
clear.preview.delay = 500
```