



PDF



DO NOT SCALE DWG ALL DIMS IN INCHES TOLERANCES .X +/- .030 .XX +/- .010 .XXX +/- .003 ANGLES +/- .5 DEG. UNLESS OTHERWISE SPECIFIED		TENACORE		
		TOP ASSEMBLY DWG. JTAG ADAPTER		
DWG SIZE	A	DWG NO. TENA003	REV A	
SCALE: 1 : 1		SHEET: 1 OF 2		



DO NOT SCALE DWG
 ALL DIMS IN INCHES
 TOLERANCES
 .X $\pm .030$
 .XX $\pm .010$
 .XXX $\pm .003$
 ANGLES $\pm .5$ DEG.
 UNLESS OTHERWISE SPECIFIED

TENACORE

BOTTOM ASSEMBLY DWG.
 JTAG ADAPTER

DWG SIZE	A	DWG NO. TENA003	REV A
SCALE: 1 : 1	SHEET: 2 OF 2		